



- A. Secure the body of the faucet (1) by twisting the threaded rod (4). Be careful not to twist too hard.
- B. Place the faucet on the selected sink or board and set the base ring (2) gasket (3) between the body of the faucet and foundation. Then, set the rubber gasket (5) and metal gasket (6) onto the threaded rods (4) and tighten the nut (7).
- C. Screw the flexible hose (8) onto the body and connect to the plumbing . Afterthen, remove the faucet aerator, run the water to drain all the impurities, reattach the faucet aerator and ensure that the faucet is working correctly by moving the handle in all directions.
- D. Check the connections for leaks.