



- A. Put the body (1) in the wall and connect it to the piping ,then fix it by the expansion screw(2) and screw(3)
- B. Take out the protect box cover (5) by screw off the screw (6)
- C. Put the panel (7) onto the body(1)
- D. Install the spout (9) by fasten the screw(8) on the spout(9)
Put the handle onto the cartridge, fasten it by the screw(11) and put the indicator(12) on the hole of handle.
- E. Last remove the faucet aerator, run the water to drain all the impurities, reattach the faucet aerator and ensure that the faucet is working correctly by moving the handle in all directions. Check the connections for leaks.