



- DE** Montageanleitung
FR Instructions de montage
EN Assembly instructions
IT Istruzioni per Installazione
ES Instrucciones de montaje
NL Handleiding
DK Monteringsvejledning
PT Manual de Instalação
PL Instrukcja montażu
CS Montážní návod
SK Montážny návod
ZH 组装说明
RU Инструкция по монтажу
HU Szerelési útmutató
FI Asennusohje
SV Monteringsanvisning
LT Montavimo instrukcijos
HR Uputstva za instalaciju
TR Montaj kılavuzu
RO Instrucțiuni de montare
EL Οδηγία συναρμολόγησης
SL Navodila za montažo
ET Paigaldusjuhend
LV Montāžas instrukcija
SR Uputstvo za montažu
NO Montasjeveiledning
BG Инструкция за употреба
UA Інструкція по збірці
AR تعليمات التجميع
JP 施工説明書
HE הוראות הרכבה





Crometta 100 1jet
26331XX0

**Crometta 100 1jet
EcoSmart+**
26333400











Crometta 100 Vario
26330XX0

**Crometta 100 Vario
EcoSmart**
26332400




Service







Crometta 100 1jet
26331XX0




Crometta 100 1jet EcoSmart+
26333400



Crometta 100 Vario
26330XX0



Crometta 100 Vario EcoSmart
26332400





DVGW

26331XXO BT0633

26330XXO BT0633

26332400 BT0633

26333400 BT0633

hansgrohe

Hansgrohe · Auestraße 5 · 9 · D-77761 Schiltach
 Telefon +49 (0) 78 36/51-1282 · Telefax +49 (0) 7836/511440
 E-Mail: info@hansgrohe.com · Internet: www.hansgrohe.com

01/2024
 9.01174.04